



## Steam Iron Troubleshooting

Water drips from my iron

Fabric is sticking on soleplate

Water drips from my iron

1. The set temperature is too low for steam ironing.

Resolve: You have used the steam boost function at a temperature setting below... Set the steam control to position dial to a setting between ... and MAX.

2. Filling opening is not properly closed

Resolve: Press the cap until you hear a click

Fabric is sticking on soleplate

Fabrics may stick to the soleplate when they are ironed at too high temperatures. To avoid sticking, you should follow the instructions in the fabric table in your instruction booklet. Try a lower temperature setting. Also, to prevent sticking you can put a cloth (e.g. a tea towel) between the iron and the fabric. If the problem still persists please [contact](#) consumer care team.